



**DREW TECHNOLOGIES**  
AN OPUS COMPANY



***MONGOOSEPRO***  
User Guide

# Contents

- Please Note ..... 3
- Copyright & Trademarks ..... 4
- Limited Warranty..... 4
- FCC Statement ..... 5
- Introduction ..... 6
- Getting to know the **MongoosePro**® ..... 6
- Driver Installation ..... 7
- J2534 Toolbox 3 ..... 13
- Maximum Voltage Per **MongoosePro**® Product..... 17
- MongoosePro**® Vehicle Connector Pin Assignments... 18
- Bluetooth Setup ..... 19
- Technical Support ..... 20
- Environmentals..... 20



## Please Note

**MongoosePro**<sup>®</sup> interfaces have been carefully designed and tested to comply with **OBDII protocols**. However, some vehicle models are not in full compliance with these protocols for various reasons. In addition, the computer control systems or sensors on any given vehicle may be malfunctioning or out of specification.

While **Drew Tech's** testing and the experiences of thousands of **MongoosePro**<sup>®</sup> users have shown the unit to be safe and reliable, there is an inherent risk in using any product that may potentially affect the operation or drive-ability of your vehicle.

If you are concerned about the operation of your vehicle at any time while using **MongoosePro**<sup>®</sup>:

- \* Pull off the roadway immediately or as soon as it is safe to do so.
- \* Disconnect the **MongoosePro**<sup>®</sup> from the **OBDII port**.
- \* Consult a licensed mechanic or automobile service center.

Please report any issues or concerns to our **Technical Support Department** at [support@drewtech.com](mailto:support@drewtech.com) or (734) 222-5228 option 3. We are open **Monday–Friday, 9:00am–5:30pm Eastern Time**. We maintain an active database of the feedback we receive, and your comments can help us continuously improve the product.

Permission is granted to copy any or all portions of this manual, provided that such copies are for use with **Drew Technologies** product and that ©2018 **Drew Technologies, Inc.**, (here-in referred to as **DrewTech**), remains on all copies. The accompanying software, provided for use with the **DrewTech** product, is also copyrighted. Permission is granted to copy this software for back-up purposes only.

## Copyright & Trademarks

Copyright 1999–2018 **Drew Technologies, Inc.**, All Rights Reserved. **MongoosePro**<sup>®</sup>, **CarDAQ**<sup>®</sup>, **ScanDAQ**<sup>®</sup>, **IMclean**<sup>®</sup>, **IMready**<sup>®</sup> and **J2534 ToolBox** are registered trademarks of **Drew Technologies, Inc.** All other trademarks and brand names are the property of their respective owners.

## Limited Warranty

**Drew Technologies, Inc.** guarantees that every **MongoosePro**<sup>®</sup> is free from physical defects in material and workmanship under normal use for one year from the date of purchase.

**In no event shall Drew Technologies, Inc.'s liability exceed the price paid for the product. Drew Technologies shall be exempt from all other claims whether based upon direct, indirect, special, incidental, or consequential damages resulting from the use of the product, its accompanying software, or its documentation.** **Drew Technologies, Inc.** makes no warranty or representation, expressed, implied, or statutory, with respect to its products or the contents or use of this documentation and all accompanying software, and specifically disclaims its quality, performance, merchantability, or fitness for any particular purpose. **Drew Technologies, Inc.** reserves the right to revise or update its products, software, or documentation without obligation to notify any individual or entity. Please direct all inquiries to:

**Drew Technologies, Inc.**  
3915 Research Park Dr  
Suite A10  
Ann Arbor, MI 48108

## FCC Statement

The wireless module has been tested and found to comply with the **FCC Part 15** and **ICRSS-210** rules. These limits are designed to provide reasonable protection against harmful interference in approved installations. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference may not occur in a particular installation. This device complies with **Part 15** of the **FCC** rules. Operation is subject to the following two conditions: **(1)** this device may not cause harmful interference, and **(2)** this device must accept any interference received, including interference that may cause undesired operation. Modifications or changes to this equipment not expressly approved by the part responsible for compliance may render void the user's authority to operate this equipment.

### Modular Approval, FCC and IC.

**FCC ID X3ZBTMOD3**

**IC 8828A-MOD3**

In accordance with **FCC Part 15**, the **SPT2632C1A.AT2** is listed above as a modular transmitter device.

## Introduction


Thank you for choosing the **MongoosePro**! The **MongoosePro** will allow you to re-flash modern vehicle controllers to stock as well as perform dealer level diagnostics on select manufacturer's vehicles. The **MongoosePro** is an SAE J2534-compliant device at a low cost. It provides a direct connection to a laptop or desktop computer via a USB connection. All of the electronics are contained in the OBDII connector shell, making it a compact and rugged vehicle communications tool. The **MongoosePro** is powered by the USB connector, so there's no need to re-start the **MongoosePro** if it is unplugged from a vehicle.

## Getting to know the MongoosePro<sup>®</sup>




## Driver Installation


1. Go to or click this link to go to the **Drewtech** downloads page:  
<http://drewtech.com/downloads/index.html>
2. Click the **Set-up** link for the respective **MongoosePro®** to be installed.
3. Click **Run** to install the software once the software has downloaded to your PC.
4. Upon receiving this screen, read, check the box next to **I Accept** then click **Install**.



5. Installing...



6. Once the setup application has finished, connect the **MongoosePro®** to the PC. Once you have gotten a message in the lower, right-hand corner of your screen that the device has been installed, click on **Activate My Device**.







- The **Device Activator** application will reopen after clicking **Activate My Device**. Click the **Activate My Device! button**.



- Select the interface device you want to activate and click **Continue**.




9. Enter the applicable information and click **Continue**.




The screenshot shows a window titled "Universal Activator Activation Window" with the Drew Technologies logo. The main heading is "To Activate Your Device, We Need To Know More About You...". Below this is a sub-heading: "We use this activation information to activate your product's warranty; Without it, your product is unprotected." The form contains the following fields: First Name, Last Name, Country, Company, Address, City, State, Zip Code, Phone, and Email. A "Continue" button is located at the bottom of the form. The footer of the window reads "PRODUCT INSTALLER".

10. Select your type of business and level of programming experience, then select the OEM's you are planning to support. Click **Continue**.




The screenshot shows the same "Universal Activator Activation Window" but with different content. The heading is "Tell us about your business...". There are two dropdown menus: "Describe your Business:" with "Aftermarket Repair Shop" selected, and "Reprogramming Experience:" with "Beginner" selected. Below these are two columns of checkboxes for "Supported OEM's":  
Left column:  Acura \ Honda,  Audi \ VW,  BMW \ Mini,  Chrysler \ Fiat Group,  Ford Group,  GM Group  
Right column:  Allison,  Caterpillar,  Cummins,  Dana,  Detroit Diesel,  John Deere  
A "Continue" button is at the bottom. The footer reads "PRODUCT INSTALLER".

11. Leave the **MongoosePro®** disconnected from the PC.



12. Plug your **MongoosePro®** to the PC, and click **OK**.



13. This is the screen you will see once your device activation is successful.




**NOTE:** Once product activation is performed successfully, you can also install the device on other PC's and not have to perform the activation procedure again.


## J2534 Toolbox 3

The purpose of the **J2534 Toolbox** is to provide current, relative information and assistance to the user. The information is provided via various walk-through documents, OEM documentation, web-links, quick-links, videos, basic diagnostic functions, connection verification and much more. The **J2534 Toolbox** should be referred to regularly as information is updated continually.


1. Locate and double-click the **J2534 Toolbox Icon** on the desktop




2. Select your interface from the drop-down menu and click **Auto Login**.




- a. **GENERAL TAB** Contains important news, current OEM concerns, training broadcast invitations and current information you should review.




- b. **SALES TAB** Connects you to the **DrewTech** website.




- c. **DIAGNOSTIC TAB** Contains relative links, some diagnostic functions, information and videos about flashing and OEM's that currently provide diagnostics via J2534.




- d. **FLASHING TAB** Contains the information pertaining to OEM J2534 flashing including links, information, walk-throughs, and some helper functions.



- e. **SUPPORT TAB** Contains functions to check driver installation, vehicle communication, updating the device, create debug logs, contact Technical Support and other resources.



- f. **TRAINING TAB** Contains general information, installation and Using OEM J2534 Application Videos with Drew Technologies products.





## Maximum Voltage Per MongoosePro® Product

Product	Max VBatt	Min VBatt CAN	Min VBatt J1850	Min VBatt K-Line	Min VBatt SCI
Chrysler	25	N/A	9	N/A	6
Ford	30	N/A	N/A	6	N/A
GM II	18	N/A	9	6	N/A
Honda	30	N/A	N/A	6	N/A
ISO/CAN	30	N/A	N/A	6	N/A
JLR	16	N/A	N/A	6	N/A
Nissan	30	N/A	9	6	N/A
Toyota 2	30	N/A	9	6	N/A
VW	30	N/A	9	6	N/A

## MongoosePro® Vehicle Connector Pin Assignments


Pin	Chrysler	Ford	GM II	Honda	ISO/ CAN	JLR	Nissan	Toyota 2	VW
1			SW CAN	PS GND / Diag X			PS GND	PS GND	PS GND
2	J1850+	J1850+	J1850+			J1850+		J1850+	
3			CAN 2+ / K-Line	CAN 2+		CAN 2+ / K-Line			CAN 2+
4									
5	GND	GND	GND	GND	GND	GND	GND	GND	GND
6	CAN+	CAN+	CAN+	CAN+	CAN+	CAN+	CAN+	CAN+	CAN+
	SCI		K-Line						
7	SCI	K-Line	K-Line	K-Line	K-Line	K-Line	K-Line	K-Line	K-Line
8			K-Line			ROSCO			
9	SCI		UART	PS GND			PS GND	PS GND	PS GND
			K-Line	Diag H					
10		J1850-				J1850-			
11			CAN 2-	CAN 2-		CAN 2-			CAN 2-
12	SCI		CAN 3+	PS 5V		PS GND	PS 5V	PS 5V	PS 5V
			K-Line						
13		FEPS	CAN 3- / K-Line			FEPS			
14	CAN- / SCI	CAN-	CAN-	CAN-	CAN-	CAN-	CAN-	CAN-	CAN-
15	L-Line	L-Line / PS	L-Line	L-Line	L-Line	L-Line	L-Line	L-Line / PS GND	L-Line
	PS GND	GND			PS GND	PS GND	PS GND		
16	VBatt	VBatt	VBatt	VBatt	VBatt	VBatt	VBatt	VBatt	VBatt

- \* PS GND = Pin Switched to Ground
- \* PS 5V – Pin Switched to +5V
- \* Nissan supports API 04.04 and 05.00


## Bluetooth Setup

**Bluetooth** is an option that can be purchased with some **MongoosePro®** versions. If you have purchased **Bluetooth**, your **MongoosePro®** will have a **BT** at the end of the model number. Please note that **DrewTech** does not recommend doing any reprogramming over **Bluetooth**.

1. Make sure your **Bluetooth** dongle is installed by inserting your **Bluetooth** dongle manufacturer media into your PC and follow the installation directions.
2. To pair your **MongoosePro® BT**, right click on the **Bluetooth icon** in the System Tray.



3. Click on **Add Device**



4. Select your device from the available options, then click **Next**.
5. Enter the pairing code **2534** in the text box and click **Next** pair the **MongoosePro® BT**.
6. Your **MongoosePro® BT** has been successfully paired with your PC.

**NOTE:** Only have one (1) **MongoosePro® BT** paired with your PC to avoid erroneous test results. The **MongoosePro®** driver will inform if you have multiple devices paired to your PC.

## Technical Support

Please contact **Drew Technologies** for technical support at [support@drewtech.com](mailto:support@drewtech.com) or (734) 222-5228 option 3.

If technical support finds it necessary for the unit to be returned for repair, you will be asked for your contact information and then provided with a **Return Merchandise Authorization number (RMA #)**. **Drew Technologies** will use the **RMA #** to track the unit through the repair process. Please write this number on the outside of your shipping box so it can be routed to the correct department. If the necessary repair is not covered by **Drew Technologies'** warranty, you will be contacted for payment arrangements.

## Environmentals

Environmental conditions, 5°C to 40°C and a Maximum relative humidity 80% for temperatures up to 31°C decreasing linearly to 50% relative humidity at 40°C

### Indoor use only

**Altitude:** 2000m above mean sea level  
**Relative humidity:** 0 to 90%  
**Over voltage category:** II  
**Pollution degree:** 2

12V  , 150mA (battery power)

5V  , 150mA (USB power)

*MONGOOSEPRO*



**DREW TECHNOLOGIES**  
AN OPUS COMPANY

3915 Research Park Drive  
Ann Arbor, MI 48018  
[drewtech.com](http://drewtech.com)

877.888.2534  
844.**REFLASH** (844.733.5274)

© 2018 Drew Technologies, Inc. All Rights Reserved.

**[www.pcbauto.it](http://www.pcbauto.it)**  
[info@pcbauto.it](mailto:info@pcbauto.it)

Viale Beniamino Gigli, 15  
60044 Fabriano AN  
Tel. +39 0732 251144  
Fax +39 0732 249253

